

NULINE

REFRIGERATION

A SIGN OF QUALITY

How to Check Hi / Lo Settings



1. Press and hold up arrow until **H_** displays
2. Press up arrow and highest temp will display
3. Press up arrow and **L_** displays
4. Press up arrow and lowest temperature will display
5. Screen will time out and go back to current temperature

Refrigerator automatically resets the hi/lo temperatures at 5.35pm daily.

Distributor

EVOCARE AUSTRALIA PTY LIMITED

A.B.N. 98 078 566 604

Trading as **EVOCARE** and **L&M EQUIPMENT**

P.O. Box 145, Everton Park Qld. 4053

Ph: 07 3355 8000

Website: <http://www.evocare.com.au>

Email: sales@evocare.com.au

workshop@evocare.com.au

warehouse@evocare.com.au

accounts@evocare.com.au



Global-Mark.com.au®